


Quick Guide for TouchUSB Touch Screen Mac Driver For Mac 10.4.x INTEL

This quick guide provides instruction for installing the Touch drivers for "Intel-based Mac." Please select the version suitable for user's Mac.


For Mac 10.4.x suggest you to update to OS to current version .

1. How to Install (OS 10.4.X)


- 1.1 Insert driver CD into CD-Rom drive.
- 1.2 Open driver CD and select correct folder for your operating system version.
- 1.3 Click TouchUSB icon to install.




Installation welcome screen




- 1.4 Select destination (hard drive) to install driver then click continue




1.5. Click the Install button.




1.6 Click Continue Installation button.



1.7 If prompted to authenticate administrator privilege, type in name and password of administrator account.




1.8 After installation is completed, click Restart button.




2. How to calibrate touch screen

2.1 Please click on Applications → TouchUSB Utility → TouchUSB to run TouchUSB utility program.



2.2 Click Calibration button to run touch screen calibration program. There are a total of three targets ('X'), each appearing one at a time. If you touch any less than three targets, calibrate again.




2.3 After successful completion of the calibration program, you will be returned to the "Touch USB Preferences" window. Click cancel button to close the window.




3. How to uninstall touch screen

3.1 Click on Applications → TouchUSB Utility → Uninstaller to uninstall the touch screen driver from your Mac.



3.2 Click Ok button to remove TouchUSB files. .

3.3 If prompted to authenticate administrator privilege, type in name and password of administrator account



3.4 Uninstall complete.

